INSTRUCTION MANUAL

HI 96701

Free Chlorine ISM

Dear Customer

Thank you for choosing a Hanna product. This manual will provide you with the necessary information for the correct use of the instrument. Please read it carefully before using the meter. If you need additional technical information, do not hesitate to e-mail us at tech@hannainst.com.

Preliminary examination:


Please examine this product carefully. Make sure that the instrument is not damaged. If any damage occured during shipment, please notify vour Dealer

- Each HI 96701 Ion Selective Meter is supplied complete with:
- Two Sample Cuvettes and Caps
- 9V Battery
- Instruction Manual
- Note: save all packing material until you are sure that the instrument works correctly. Any defective item must be returned in its original packina

$ec{m{\imath}}$ For more details about spare parts and accessories see "Accessories".

Technical specifications:	
Range	0.00 to 5.00 mg/L of Free Cl ₂
Resolution	0.01 mg/L (0.00-3.50 mg/L); 0.10 mg/L (above 3.50 mg/L)
Accuracy	± 0.03 mg/L $\pm 3\%$ of reading at 25°C
Typical EMC Dev.	±0.01 mg/L
Light Source	Tungsten lamp
Light Detector	Silicon Photocell with narrow band interference filter @ 525 nm
Method	Adaptation of USEPA method 330.5 and Standard Method 4500-CI G.
Environment	0 to 50°C (32 to 122°F); max 95% RH non-condensing
Battery Type	1 x 9 volt
Auto-Shut off	After 10' of non-use in measurement mode; after 1 hour of non-use in calibration mode; with last reading reminder.
Dimensions	192 x 104 x 69 mm (7.6 x 4.1 x 2.7")
Weight	360 g (12.7 oz.).

Functional description:



- 1. GLP/A key: press to enter GLP mode. In calibration mode press to edit the date and time
- 2. CAL CHECK key: press to perform the validation of the meter, or press and hold for three seconds to enter *calibration mode*.
- 3. ZERO/CFM key: press to zero the meter prior to measurement, to confirm edited values or to confirm factory calibration restore.
- 4. READ/►/TIMER key: In *measurement mode*, press to make a measurement, or press and hold for three seconds to start a pre-programmed countdown prior to measurement. In GLP mode press to view the next screen.
- 5. ON/OFF key: to turn the meter on and off.
- 6. Liquid Crystal Display (LCD)
- 7. Cuvette alianment indicator
- 8 Cuvette holder

DISPLAY ELEMENTS DESCRIPTION



- 1. The measuring scheme (lamp, cuvette, detector), appears during different phases of zero or reading measurement
- 2. Error messages and warnings
- 3. The battery icon indicates the charge state of the battery
- 4. The hourglass appears when an internal check is in progress
- 5. Status messaaes
- 6. The chronometer appears when the reaction timer is running
- 7. The month, day and date icons appear when a date is displayed
- 8. Four diait main display
- 9. Measuring units
- 10. Four digit secondary display

Errors and warnings:

ON ZERO READING:

Err

ON SAMPLE READING:

Err

2Fc0


0004



Light Low: There is not enough light to perform a measurement. Please check the preparation of the zero cuvette.

No light. The instrument cannot adjust the light level. Please check that the sample does not contain any debris.





instructions of the measurement procedure for

Under range: A blinking "0.00" indicates that the sample absorbs less light than the zero reference. Check the procedure and make sure you use the same cuvette for reference (zero) and measurement



Over Range: A flashing value of the maximum concentration indicates an over range condition. The concentration of the sample is beyond the programmed range; dilute the sample and re-run the test.

Standard Low: The standard reading is less

DURING CALIBRATION PROCEDURE



Standard Hiah: The standard reading is higher than expected.

than expected.

OTHER ERRORS AND WARNINGS:



Cap error: Appears when external light enters in the analysis cell. Assure that the cuvette cap is present.



Battery low: The battery must be replaced soon

dEAd ЬЯЕЕ

2

3

10ml

6**0**>


8-9

. - 00 -

. 00°59

Dead battery: This indicates that the battery is dead and must be replaced. Once this indication is displayed, normal operation of the instrument will be interrupted. Change the battery and restart the meter.

Measurement procedure:



- 3. Fill the cuvette with 10 mL of unreacted sample, up to the mark, and replace the can
- 4. Place the cuvette into the holder and ensure that the notch on the cap is positioned securely into the groove.
- 5. Press ZERO/CFM and the lamp, cuvette and detector icons will appear on the display, depending on the measurement phase.
- 6. After a few seconds the display will show "-0.0-". The meter is now zeroed and ready for measurement.
- 7. Remove the cuvette.
- 8. Add the content of one packet of HI 93701-0 Free Chlorine reagent.
- 9. Replace the cap and shake gently for 20 seconds (or 2 minutes in case of seawater analysis).
- 10 Replace the cuvette into the holder and ensure that the notch on the cap is positioned securely into the groove.
- 11 Press and hold READ/>/TIMER for three seconds. The display will show the countdown prior to measurement. The beeper is plaving a beep at the end of countdown period.
- Alternatively, wait for 1 minute and just press **READ**/>/TIMER.
- In both cases, the lamp, cuvette and detector icons will appear on the display, depending on the measurement phase. 12 • The instrument directly displays concentration
 - in ma/L of free chlorine on the Liquid Crystal Display.







INTERFERENCES:

• Positive error: Bromine, Oxidized Manganese and Chromium. Chlorine dioxide. Ozone and Indine

or

150.

- 0.0 -

60)

- Alkalinity above 250 ma/L CaCO or acidity. above 150 ma/L CaCO will not reliably **()** develop the full amount of color or it may rapidly fade. To resolve this, neutralize the 12 sample with diluted HCl or NaOH.
- In case of water with hardness areater than 500 ma/L CaCO., shake the sample for approximately 2 minutes after adding the powder reagent.

Validation and Calibration procedures

Warnina: do not validate or calibrate the instrument with standard solutions other than the Hanna CAL CHECK™ Standards, otherwise erroneous results will be obtained

For accurate validation and calibration results, please perform tests at room temperature (18 to 25°C: 64.5 to 77.0°F).

i Use the Hanna CAL CHECK™ cuvettes (see "Accessories") to validate or calibrate instruments.

VALIDATION

- 1. Turn the meter on by pressing ON/OFF.
- 2. When the beeper sounds briefly and the Validation **w** LCD displays dashes, the meter is ready.
- 3• Place the CAL CHECK™ Standard HI 96701-11 Cuvette A into the holder and ensure that the notch on the cap is positioned securely into the groove.
- 4. Press ZERO/CFM and the lamp, cuvette and detector icons will appear on the 4-5 display, depending on the measurement phase
- **5** After a few seconds the display will show "-0.0-" The meter is now zeroed and **€●**► ready for validation.
- 6. Remove the cuvette.
- **7** Place the CAL CHECK[™] Standard HI 96701-11 Cuvette B into the holder and ensure that the notch on the cap is positioned securely into the groove.
- 8. Press CAL CHECK key and the lamp. cuvette and detector icons together with "CAL CHECK" will appear on the display. depending on the measurement phase.
- 9. At the end of the measurement the display will show the validation standard value. The reading should be within specifications as reported on the CAL CHECK™ Standard Certificate. If the value is found

out of specifications, please check that the cuvettes are free of fingerprints, oil or dirt and repeat validation. If results are still found out of specifications then recalibrate the instrument

CALIBRATION

- procedure at any time by pressing CAL CHECK or ON/OFF keys.
- 1. Turn the meter on by pressing ON/OFF.
- LCD displays dashes, the meter is ready. 3. Press and hold CAL CHECK for three
 - seconds to enter calibration mode. The display will show "CAL" during calibration 3 procedure. The blinking "ZERO" asks for instrument zeroina.
- 4• Place the CAL CHECK[™] Standard HI 96701-11 Cuvette A into the cuvette holder and ensure that the notch on the cap is positioned securely into the groove.
- 5. Press ZERO/CEM and the lamp, cuvette and detector icons will appear on the display. depending on the measurement phase.
- "-0 0-" The meter is now zeroed and asks for reading calibration standard.
- 7. Remove the cuvette. 8. Place the CAL CHECK™ Standard HI 96701-11 Cuvette B into the holder
- positioned securely into the groove. 9. Press READ/>/TIMER and the lamp. cuvette and detector icons will appear on
- **10** The instrument will show for three seconds
- Note: If the display shows "STD HIGH", the standard value was too high. If the display shows "STD LOW", the standard value was too low. Verify that both CAL CHECK[™] Standard HI 96701-11 Cuvettes. A and B are free from fingerprints or dirt and that they are inserted correctly.
- 11 Then the date of last calibration (e.q.: "01.08.2009") appears on the display, or "01.01.2009" if the factory calibration was selected before. In both cases the year number is blinking, ready for date input.

10 L

≥ 2580 €

1

- 0.0 -

180.

*****•

- Note: It is possible to interrupt the calibration
- 2. When the beeper sounds briefly and the Calibration **v**
- 6. After a few seconds the display will show ready for calibration. The blinking "READ" 5-6
- and ensure that the notch on the cap is
- the display, depending on the measurement 8 nhase
- the CAL CHECK[™] standard value.
- 9-10

12• Press GLP/▲ to edit the desired year 11-13 (2009-2099). If the key is kept pressed. the year number is automatically increased. 13. When the correct year has been set, press

0 108

A 1.

20

ZERO

168

2009

GLP

09.08

2009

GLP

ZERO

Last

Date 🔻

GLP

Calibration

FERL

Stor

≥≥ooos_

- ZERO/CFM or READ/ /TIMER to confirm. Now the display will show the month blinkina
- 14 Press GLP/ to edit the desired month (01-12). If the key is kept pressed, the month number is automatically increased
- 15• When the correct month has been set. press ZERO/CFM or READ/>/TIMER to confirm. Now the display will show the dav blinkina.
- 16 Press GLP/▲ to edit the desired day (01-31). If the key is kept pressed, the day number is automatically increased.
- Note: It is possible to change the editing from day to year and to month by pressina RFAD/>/TIMFR
- 17 Press ZERO/CFM to save the calibration dato
- 18. The instrument displays "Stor" for one second and the calibration is saved 17 19. The instrument will return automatically to *measurement mode* by displaying dashes 18 on the ICD

GLP

In GLP mode, the last calibration date can be verified and the factory calibration can be restored.

LAST CALIBRATION DATE

- 1 Press GLP/▲ to enter GLP mode. The calibration month and day will appear on the main display and the year on the secondary display.
- 2. If no calibration was performed, the factory calibration message, "F.CAL" will appear 2 on the main display and the instrument returns to measurement mode after three seconds.

FACTORY CALIBRATION RESTORE

It is possible to delete the calibration and restore factory calibration.

- I Press GLP/▲ to enter GLP mode.
- 2. Press READ/>/TIMER to enter in the factory calibration restore screen. The ERL instrument asks for confirmation of user calibration delete
- 3. Press ZERO/CEM to restore the factory 3-4 calibration or press GLP/A again to abort factory calibration restore.
- donE 4. The instrument briefly indicates "donE" upon restoration of factory calibration prior to returning to *measurement mode*.

Batterv management

To save the battery, the instrument shuts down after 10 minutes of non-use in measurement mode and after 1 hour of non-use in calibration mode. If a valid measurement was displayed before <u>____</u>20.,,t auto-shut off, the value is displayed when the

instrument is switched on. The blinking "ZERO" means that a new zero has to be performed.

One fresh battery lasts for arround 750 measurements, depending on the light level.

The remaining battery capacity is evaluated at the instrument startup and after each measurement.

- The instrument displays a battery indicator with three levels as follows: 3 lines for 100 % capacity
- 2 lines for 66 % capacity
- 1 line for 33 % capacity
- Battery icon blinking if the capacity is under 10 %.

If the battery is empty and accurate measurements can't be taken any more, the instrument shows "dEAd bAtt" and turns off.

To restart the instrument, the battery must be replaced with a fresh one. To replace the instrument's battery, follow the steps:

- Turn the instrument off by pressing ON/OFF.
- · Turn the instrument upside down and remove the battery cover by turning it counterclockwise.



- Extract the battery from its location and replace it with a fresh one.
- · Insert back the battery cover and turn it clockwise to close.

Accessories:

Factory

Calibration

Restore **v**

READ TIMER

ZERO CFM

2

REAGENT SETS HI 93701-01 Reagents for 100 Free Chlorine tests HI 93701-03 Reagents for 300 Free Chlorine tests OTHER ACCESSORIES HI 96701-11 CAL CHECK[™] Standard Cuvettes (1 set) HI 721310 9V battery (10 pcs) HI 731318 Cloth for wiping cuvettes (4 pcs) HI 731331 Glass cuvettes (4 pcs) HI 731335 Caps for cuvettes (4 pcs) HI 93703-50 Cuvette cleaning solution (230 mL).

Warranty

HI 96701 is warranted for two years against defects in workmanship and materials when used for its intended purpose and maintained accordina to the instructions

This warranty is limited to repair or replacement free of charge. Damages due to accident, misuse, tampering or lack of prescribed maintenance are not covered.

If service is required, contact your dealer. If under warranty, report the model number, date of purchase, serial number and the nature of the failure. If the repair is not covered by the warranty, you will be notified of the charaes incurred.

If the instrument is to be returned to Hanna Instruments, first obtain a Returned Goods Authorization Number from the Customer Service Department and then send it with shipment costs prepaid. When shipping any instrument, make sure it is properly packaged for complete protection. To validate your warranty, fill out and return the enclosed warranty card within 14 days from the date of purchase.

Recomm ndations for Users

IST9670

11/10

Before using these products, make sure that they are entirely suitable for your specific application and for the environment in which they are used

Oneration of these instruments may cause unacceptable interferences to other electronic equipments, this requiring the operator to take all peressary steps to correct interferences Any variation introduced by the user to the supplied equipment may degrade the instrument's EMC

nerformance

, To avoid damages or burns, do not put the instrument in microwave oven. For yours and the instrument safety do not use or store the instrument in hazardous environments

Hanna Instruments reserves the right to modify the design, construction and appearance of its products without advance notice.

For additional information, contact your dealer or the nearest

Hanna Customer Service Center. To find the Hanna Office in your area, visit our web site





